




16 individually alignable light sensors

Sensors automatically calibrate when turned on

Recalibrate at the push of a button

USB powered



Detachable for easy transport and maintenance

Switch between audio and control voltage output

16 control voltage outputs